



JINAN LIJIANG AUTOMATION EQUIPMENT CO.,LTD.
ADD: No.10,Hehai Industrial Park,Meilibei Road,Jinan,China
TEL:+86-531-85960498 FAX:+86-531-87562846

灌装机安装要求清单

List of Installation Requirements of Desiccant Filling Machine

由于不同设备所需要安装条件和工具不同，为提高工作效率，节省双方时间，特附《机器安装要求清单》一份。希望客户能给予配合，在我方技术人员到场之前准备好清单上所列条目，以便人员到位后可以立刻开展工作.谢谢您的合作！

Due to the different installation conditions and tools required by different equipment, in order to improve work efficiency and save time on both sides, a copy of the 《Machine Installation Requirements List》 is attached as below. We hope that the customer can cooperate and prepare the items listed on the list before the technicians arrive. So that the technicians can start working immediately after the arrival. Thank you for your cooperation!

请提供如下 Please provide as below:

1. 可以安装设备的场地,灌装机须视生产适当安排位置 Proper place where equipment can be installed,as the filling machine will be placed accordingly.
2. 提前将气源安装到位,气源要求: 需要 2-3 个接口 (气流量不低于 2000L/MIN。需要客户提供气管直径 12mm、10mm (气管长度是气源到机器的距离) Install the air source in place in advance, the air source requirements: 2-3 interfaces are required (the air flow is not less than 2000L/MIN. The customer needs to provide the tracheal diameter 12mm, 10mm (the length of the gas pipe is the distance from the gas source to the machine).
3. 提前安装电源, 要求 220V。 Install the power supply in advance, which requires 220V of voltage.
4. 调试机器用的铝框及丁基胶 Aluminum frame and butyl rubber for machine debugging.